
189

1. 30 penny nail penetrate a 4" dry timber?
2. 50 penny nail penetrate a 4 1/2" green timber?
3. 8 box gauge nail penetrate a 2" green girder?
4. 14 common gauge nail penetrate a 3" green girder?
5. 15 common gauge nail penetrate a 2" dry dimension?
6. 9 penny nail penetrate a 4 1/2" dry joist?
7. 9 box gauge nail penetrate a 1 1/2" green plank?
8. 6 penny nail penetrate a 3/4" dry board?
9. 2 penny nail penetrate a 1 1/2" green beam?
10. 6 penny nail penetrate a 3" green timber?
11. 20 penny nail penetrate a 2 1/2" dry board?
12. 8 common gauge nail penetrate a 3" green board?
13. 3 common gauge nail penetrate a 4" dry timber?
14. 30 penny nail penetrate a 3/8" dry dimension?
15. 6 penny nail penetrate a 3 1/2" green timber?
16. 7 penny nail penetrate a 3" dry girder?

1. pilot hole for a 8 gauge screw?
2. countersink hole for a 4 gauge screw?
3. countersink hole for a 14 gauge screw?
4. pilot hole for a 6 gauge screw?
5. countersink hole for a 6 gauge screw?
6. clearance hole for a 11 gauge screw?
7. countersink hole for a 14 gauge screw?
8. clearance hole for a 12 gauge screw?
9. countersink hole for a 1 gauge screw?
10. pilot hole for a 14 gauge screw?
11. pilot hole for a 2 gauge screw?
12. countersink hole for a 3 gauge screw?
13. pilot hole for a 11 gauge screw?
14. pilot hole for a 2 gauge screw?
15. pilot hole for a 7 gauge screw?
16. pilot hole for a 14 gauge screw?